


Home Key™ Components



(can be set up for left- or right-handed use)

Home Key Uses:

The Home Key is a portable, tear-off display and controller for your Home Heartbeat system.

Perfect for:

- Visually monitoring your home's status
- Setting up Home Heartbeat sensors
- Automatically setting the system to send cell phone and text message alerts after you have left home

Buy one for every member of your family!

FCC Statement

(Compliance Statement, Part 15.19): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING (Part 15.21): Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This portable transmitter with its antenna complies with FCC's RF exposure limits for general population / uncontrolled exposure.

Industry Canada Statement

The term "IC" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Interference

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, then the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into a power source on different circuit than the receiver.

Home Key Maintenance

Cleaning the Home Key

Clean with a soft, dry cloth.

To check Home Key battery level

Using the Home Key, highlight the Home Key icon. Click the thumbwheel once and note the battery status on the bottom line of the screen.

Servicing the Home Key Rechargeable Battery

If you notice that your Home Key, after charging, is not holding the charge for the expected 5-7 days, please contact Eaton at 1-800-813-2199. The battery in the Home Key is a lithium cell and must be serviced by a trained technician.

Home Key Use

The battery cell in the Home Key is intended for use at ordinary temperatures where anticipated high temperature excursions are not expected to exceed 212°F (100°C). WARNING: Risk of Fire, Explosion, or Burns. Do Not Crush, Disassemble, Heat Above 212°F (100°C), Incinerate.

Home Key Disposal

Dispose of the Home Key, which contains a rechargeable battery, in accordance with local environmental laws. Your local recycling center can provide guidelines for proper battery disposal.

IM00416002E Rev. 2
Part No.: 67A5004H02
© 2006 Eaton Corporation

HOMEheartbeat™
Home Key™


EATON

EATON

Home Key™

1 Charge

CHARGE the Home Key by sliding it into the Slide Channel on the top of the Base Station until the Base Station's green LED light begins to flash. When the green LED on the Base Station stops blinking, the Home Key is fully charged. It may take up to three hours for a full charge.




To check the Home Key battery level, **ROLL** the thumbwheel, highlight the Home Key icon, and **CLICK** once. You will see the battery status on the bottom line of the screen.


TIP: You can adjust how often your Home Key needs to be recharged, as well as how often it "heartbeats" (to get system updates). Scroll over to the Home Key icon, **DOUBLE-CLICK** the thumbwheel, and choose **Battery Life** to reveal the options. Quick updates provide a more responsive system, but use more battery power. Hourly updates use less battery power.

2 Set up

REMOVE the Home Key from the Base Station. **CLICK** the Home Key thumbwheel to turn on the screen and **SLIDE** the Home Key into the Base Station again from either the left or right side.




Follow the instructions on the Home Key screen to name the Home Key and set the beep and battery life options. If you would like to change your options later, **DOUBLE-CLICK** the thumbwheel under the Home Key icon.



TIP: Your Home Key can be set up to display information in either left-handed or right-handed orientation. To change the orientation, simply dock it to the Base Station from the appropriate side.

3 Use

At home, in range of the Base, use the Home Key to monitor your HomeHeartbeat system. Alerts sent by sensors will show up on the Home Key screen.



Away from home, you can get cell phone text messages or email alerts for sensors you set up with "CallMe" Awareness, when you set the Global "CallMe" options to Call me always or Automatic call me.



Need help? Call **1-800-813-2199** for customer support or visit www.homeheartbeat.com

If Your Home Key . . .

- will not respond, it may need to be charged.
- goes in and out of range consistently while at home, consider getting a Home Heartbeat Range Extender.

EATON